


# PUXADORES DE MÓVEL / FURNITURE KNOBS / POMOS DE MUEBLE.

## IN.22.103

EN 1.4301-Satinado/Satin/Satin

**Puxador de móvel/**

Furniture knob /  
Pomo de mueble /




## IN.22.100

EN 1.4301-Satinado/Satin/Satin

**Puxador de móvel/**

Furniture knob /  
Pomo de mueble /




## IN.22.101

EN 1.4301-Satinado/Satin/Satin

**Puxador de móvel/**

Furniture knob /  
Pomo de mueble /



## IN.22.102

EN 1.4301-Satinado/Satin/Satin

**Puxador de móvel/**

Furniture knob /  
Pomo de mueble /

	A	B
IN.22.102.10	Ø10	20
IN.22.102.14	Ø14	20
IN.22.102.19	Ø19	25
IN.22.102.25	Ø25	28

